

EP.L3800 Elevator Control Panel

ACCESSORIES




Biometrics Reader




RFID Reader



HIO



HIO.EXP




- Support 8 floors by default (expandable to 136 Floors max.)
- Support timezone control bypass for individual floor
- Support up to 4 readers max.
- Support both RFID & biometrics readers
- Emergency bypass function by software
- Emergency bypass function by key Switch

Ordering Information

EP.L3800.PSU

Entrypass 4 Readers Advanced Serial Elevator Control Panel with Power Supply Unit

Basic System Diagram



ENTRYPASS CORPORATION SDN BHD

Tel : +60-3-8068 1929
 Fax: +60-3-8068 1922
www.entypass.net

40, Jalan TPP 1/10, Taman Industri Puchong,
 Bt. 12, Jalan Puchong, 47100 Puchong,
 Selangor Darul Ehsan, Malaysia